# antibodies .- online.com





### Datasheet for ABIN4368201

## **Ni-NTA Agarose**

**Images** 



#### Overview

Overview	
Quantity:	10 mL
Application:	Purification (Purif)
Product Details	
Purpose:	Specific binding and purification of his-tagged proteins
Brand:	HighSpec
Sample Type:	Cell Culture Supernatant, Cell Lysate, Tissue Lysate
Specificity:	Affinity to His-tagged proteins
Characteristics:	<ul> <li>High binding capacity up to 80 mg/mL</li> <li>Suitable for high flow rates in batch and FPLC</li> <li>Stable in buffer containing 10 mM DTT and 1 mM EDTA</li> <li>Delivered as 20 mL of a 50 % suspension</li> <li>Average agarose bead size: 100 µm</li> </ul>
Components:	Affinity Agarose
Material not included:	<ul> <li>Lysis Buffer</li> <li>Wash Buffer</li> <li>Elution Buffer</li> <li>Ice bath</li> <li>Refrigerated centrifuge for 50 mL tube (min 10,000 x g)</li> <li>50 mL centrifuge tube</li> <li>Micropipettor and Micropipetting tips</li> <li>Disposable gravity flow columns with capped bottom outlet, 2 ml</li> <li>pH meter</li> <li>End-over-end shaker</li> </ul>

Product Details	
	SDS-PAGE buffers, reagents and equipment     Optional: Western Blot reagents and equipment
Bead Ligand:	Ni-NTA
Bead Matrix:	Agarose beads
Bead Size:	100 μm
Application Details	
Comment:	KD of NTA to 6xHis-tag: ca 10 μM
	Sample Volume for an assay: >200 mL E.coli culture volume or corresponding quantity.  Protocol can be scaled up easily.
Sample Volume:	200 mL
Assay Time:	4 - 5 h
Protocol:	Purification of his-tagged protein in batch gravity flow or on FPLC columns
Reagent Preparation:	<ul> <li>A Purification under native conditions:</li> <li>Native Lysis buffer: NaH2P04 50 mM, NaCl 300 mM, Imidazole 10 mM, pH 8</li> </ul>

- Native Lysis buffer: NaH2PO4 50 mM, NaCl 300 mM, Imidazole 10 mM, pH 8
   Optional: Add 1 tablet protease inhibitor cocktail to the Lysis Buffer.
   Tip: Lysis Buffer contains 10 mM imidazole to prevent binding of untagged proteins. If Histagged proteins do not bind under these conditions, reduce the imidazole concentration to 1-5 mM
- Native Wash buffer: NaH2PO4 50 mM, NaCl 300 mM, Imidazole 20 mM, pH 8
- Native Elution buffer: NaH2PO4 50 mM, NaCl 300 mM, Imidazole 250- 500 mM, pH 8
   Additional chemicals required: Lysozyme, Benzonase® nuclease,
   Optional: Protease inhibitor cocktail

#### B Purification under denaturing conditions:

- Denaturing Lysis buffer: NaH2PO4 100 mM, Tris base 10 mM, Urea 8 M, pH 8.0,
   Optional: Benzonase® nuclease (e.g. Merck Milipore, #707464)
- Denaturing Wash buffer: NaH2PO4 100 mM, Tris base 10 mM, Urea 8 M, pH 6.3NaH2PO4 100 mM
- Denaturing Elution buffer: NaH2PO4 100 mM, Tris base 10 mM, Urea 8 M, pH 4.5
   Tip: If the target protein is acid-labile, elution can be performed with 250-500 mM imidazole.
   Note: Due to urea dissociation, adjust the pH immediately before use.

#### Assay Procedure:

#### A Protocol for purification under native conditions:

- 1. Thaw the E. coli cell pellets corresponding to 200 mL bacterial culture on ice for 15 min. Optional: Freezing the cell pellet at -20 °C for 30 min prior to incubation at room temperature improves lysis by lysozyme.
- 2. Resuspend the cell pellet in 10 mL Native Lysis Buffer supplemented with 1 mg/mL lysozyme, and pour it into a 50 mL conical centrifuge tube.
- 3. If the solution is very viscous, add 3 units Benzonase® per mL E.coli culture volume to the lysis buffer. Alternatively or additionally, sonicate the lysate to improve cell disruption.
- 4. Incubate on an end-over-end shaker at room temperature for 30 min, or at 4 °C for 1 h, depending on the temperature stability of the protein.
- 5. Centrifuge the lysate for 30 min at  $10,000 \times g$  and 2-8 °C. Carefully collect the supernatant without touching the pellet.
  - Note: The supernatant contains the cleared lysate fraction. We recommend to take aliquots of all fractions for SDS-PAGE analysis.
- 6. Resuspend the HighSpec Ni-NTA Agarose by inverting the bottle until the suspension is homogeneous. Transfer 1 mL of the 50 % suspension (corresponding to 500  $\mu$ L bed volume) to a 15 mL conical centrifuge tube. Allow the resin to settle by gravity and remove the supernatant.
  - Tip: Alternatively, resin equilibration can be performed directly in the disposable gravity flow column.
- 7. Add 2.5 mL Native Lysis Buffer and gently resuspend the slurry to equilibrate the resin. Allow the resin to settle by gravity and remove 2 mL supernatant.
- 8. Add 10 mL cleared lysate to the equilibrated HighSpec Ni-NTA Agarose resin and incubate at 4 °C for 1 h on an end-over-end shaker.
  - Tip: Alternatively, batch binding can be performed directly in a gravity flow column with closed bottom and top outlets.
- 9. Transfer the binding suspension to a disposable gravity flow column with a capped bottom outlet. Use Lysis Buffer to rinse the centrifuge tube and remove resin adhered to the wall.
- 10. Remove the bottom cap of the column and collect the flow-through.
- 11. Wash the column with 5 mL Native Wash Buffer. Repeat the washing step at least 3 times.
- 12. Elute the His-tagged protein 5 times using 0.5 mL Native Elution Buffer. Collect each eluate in a separate tube and determine the protein concentration of each fraction. Optional: Incubate the resin for 15 min in Elution Buffer before collecting the eluate to increase protein yields.
- 13. Analyze all fractions by SDS-PAGE.

  Note: Do not boil membrane proteins. Instead, incubate samples at 46 °C for 30 min in preparation for SDS-PAGE analysis.
- 14. Optional: Perform Western Blot experiment using PentaHis Antibody.

#### B Protocol for purification under denaturing conditions:

- 1. Thaw the E. coli cell pellet on ice.
- 2. Resuspend the cell pellet in 10 mL Denaturing Lysis Buffer. Optional: Benzonase® can be added to the lysate to reduce viscosity caused by nucleic acids (3 U/mL bacterial culture). Nucleic acids can also be sheared by passing the lysate 10 times through a fine-gauge needle.


- 3. Incubate at room temperature for 30 min on an end-over-end shaker.
- 4. Centrifuge the lysate for 30 min at room temperature and 10,000 x g. Collect the supernatant. Note: The supernatant contains the cleared lysate fraction. We recommend to take aliquots of all fractions for SDS-PAGE analysis.
- 5. Resuspend the HighSpec Ni-NTA Agarose by inverting the bottle until the suspension is homogeneous. Transfer 1 mL of the 50 % suspension (corresponding to 0.5 mL bed volume) into a 15 mL conical centrifuge tube. Allow the resin to settle by gravity and remove the supernatant.
- 6. Add the cleared lysate to the resin and incubate the mixture for 1 h at room temperature on an end-over-end shaker.
  - Tip: Alternatively, batch binding can be done directly in a gravity flow column with closed top and bottom outlet.
- 7. Transfer the binding suspension to a disposable gravity flow column with a capped bottom outlet. Use Lysis Buffer to rinse the centrifuge tube and remove resin adhered to the wall.
- 8. Remove the bottom cap of the column and collect the flow-through.
- 9. Wash the column with 5 mL Denaturing Wash Buffer. Repeat the washing step at least 3 times.
- 10. Elute the His-tagged protein 5 times using 0.5 mL Denaturing Elution Buffer. Collect each eluate in a separate tube and determine the protein concentration of each fraction.


  Tip: If the target protein is acid-labile, elution can be performed with 250-500 mM imidazole.
- 11. Analyze all fractions by SDS-PAGE.
  Note: Do not boil membrane proteins. Instead, incubate samples at 46 °C for 30 min in preparation for SDS-PAGE analysis.
- 12. Optional: Perform Western Blot experiment using PentaHis Antibody.


Calculation of Results:	Analyze by SDS-PAGE, Bradford Assay or spectrophotometrically.
Restrictions:	For Research Use only
Handling	
Format:	Liquid

4°C

Storage:







#### **SDS-PAGE**

**Image 1.** Fig. 1: High dynamic binding capacity of PureCube 100 Ni-NTA Agarose. GFP was spiked into E.coli lysates and purified on a 1 mL PureCube Cartridge filled with PureCube 100 Ni-NTA Agarose at flow rates from 1 to 7 ml/min, and in a gravity flow batch procedure. Left: Flow diagram, Right: SDS-PAGE analysis of elution fractions 1-4 (E1-4).

**Image 2.** Fig.2: Excellent protein recovery with PureCube 100 Ni-NTA Agarose. GFP was spiked into E.coli lysates in defined quantities (10, 5, 2.5, 1.25, and 0.625 mg) and purified on a 1 mL PureCube Cartridge filled with PureCube 100 Ni-NTA Agarose. Recovered GFP was quantified by absorption at 488 nm.